

Section

DO NOT SCALE


Notes

This drawing shows Newton 803 to the wall as a damp proofing solution.

The wall membrane should be extended to just above a viable DPC or 100mm above the height of the recorded rising damp or salt band.

A) If insulating in front of the wall membrane a vapour control layer may be required to prevent interstitial condensation, see Guidance Note GD-01.

A) The timber floor should be isolated from the wall to prevent any capillary movement of moisture. A gap is required between the wall and the floorboards. Where timber joists sit in or against the wall the ends should either be wrapped in a dpm or have a suitable timber treatment.



To access further details and relevant technical information please call our Technical Team on 01732 360095 or refer to our [website](#).

System 800 Damp Proofing

Newton 803 Wall membrane with dry lining frame finish into timber floor void

NOTE: This is a Newton damp proofing detail and copyright remains with John Newton & Co. Ltd. (trading as Newton Waterproofing Systems). Any specification/advice provided is only valid if used with products supplied by John Newton & Co. Ltd. For the design of the structure, please use a professional designer. Please refer to product data sheets before installation of our products. Newton Waterproofing Systems reserve the right to update drawings and product literature at any time.