


Section

DO NOT SCALE

Notes



This drawing shows Newton 803 Newtonite or Newton 805 Newlath to the wall linking to Newton 802-DPM below a new slab as damp proofing solution.

The wall membrane should be extended to 100mm above the height of the recorded rising damp or salt band. At the top edge of the membrane ensure that the plasterboard oversails the top of the membrane to the untreated wall by at least 500mm, with staggered joints to adjoining boards.

Please refer to plasterboard on dabs specification within the installation instructions of Newton Meshed Membranes.

Newton Mesh Plugs should be fixed at 250-300mm centers.

To access further details and relevant technical information please call our Technical Team on 01732 360095 or refer to our [website](#).

System 800 Damp Proofing

Meshed wall membrane with dot & dab finish linking to DPM below slab

NOTE: This is a Newton damp proofing detail and copyright remains with John Newton & Co. Ltd. (trading as Newton Waterproofing Systems). Any specification/advice provided is only valid if used with products supplied by John Newton & Co. Ltd. For the design of the structure, please use a professional designer. Please refer to product data sheets before installation of our products. Newton Waterproofing Systems reserve the right to update drawings and product literature at any time.